



**PROSTEP WOOD** is a step nosing profile in real oak with aluminium base. Its 90° shape makes a perfect and elegant nosing for modern stairs and steps in ceramic-tile-terracotta-wood for indoor and outdoor environments. Attractive.  
**PROSTEP WOOD** may be treated and painted subsequently at the time of laying, according to the finishes chosen for the staircase.



**NATURAL OAK + ALUMINIUM BASE**  
 bar length 2,7 LM - pack. 10 Pcs - 27 LM

| Article  | H mm |  |  |
|----------|------|--|--|
| PTPW 10  | 10   |  |  |
| PTPW 125 | 12,5 |  |  |

H. 15 mm ON REQUEST

#### COLOURS



(for a precise assessment of colours and finishes, see the relative enclosed sheet)



**NATURAL OAK + ALUMINIUM BASE**  
 bar length 1,20-1,80 LM - pack. 10 Pcs - 12/18 LM


| Article                         | H mm |  |
|---------------------------------|------|--|
| PTPW 1020 (bar length 1,20 LM)  | 10   |  |
| PTPW 12520 (bar length 1,20 LM) | 12,5 |  |
| PTPW 1080 (bar length 1,80 LM)  | 10   |  |
| PTPW 12580 (bar length 1,80 LM) | 12,5 |  |

#### ITEMS SUPPLIED ALREADY ASSEMBLED


*Treat the wood appropriately with paint or oil.*

## PROSTEP WOOD

NATURAL OAK  
 + ALUMINIUM BASE



#### EXAMPLES AND INSTRUCTIONS FOR LAYING METHODS



1: Choose the "PROSTEP WOOD" with suitable height for the thickness of the covering of the step or staircase. 2: Apply the adhesive onto the area of application of the profile. 3: Lay and align the profile, cut to the necessary length, pressing the perforated flange into the adhesive. 4: Lay the step covering, aligning it so that the top edge of the profile is "flush" with the covering. 5: Fill the profile/covering area of contact with adhesive to prevent any infiltration.

**PROSTYLE WOOD** is a step nosing profile in real oak with aluminium base. Its rounded "torus/fret" shape makes a perfect and elegant nosing for stairs and steps in ceramic-tile-terracotta-wood for indoor and outdoor environments. Attractive.  
**PROSTYLE WOOD** may be treated and painted subsequently at the time of laying, according to the finishes chosen for the staircase.



**NATURAL OAK + ALUMINIUM BASE**  
 bar length 2,7 LM - pack. 10 Pcs - 27 LM

| Article  | H mm |  |  |
|----------|------|--|--|
| PSYW 10  | 10   |  |  |
| PSYW 125 | 12,5 |  |  |

H. 15 mm ON REQUEST

#### COLOURS



(for a precise assessment of colours and finishes, see the relative enclosed sheet)



**NATURAL OAK + ALUMINIUM BASE**  
 bar length 1,20-1,80 LM - pack. 10 Pcs - 12/18 LM


| Article                         | H mm |  |
|---------------------------------|------|--|
| PSYW 1020 (bar length 1,20 LM)  | 10   |  |
| PSYW 12520 (bar length 1,20 LM) | 12,5 |  |
| PSYW 1080 (bar length 1,80 LM)  | 10   |  |
| PSYW 12580 (bar length 1,80 LM) | 12,5 |  |

#### ITEMS SUPPLIED ALREADY ASSEMBLED


*Treat the wood appropriately with paint or oil.*

## PROSTYLE WOOD

NATURAL OAK  
 + ALUMINIUM BASE



#### EXAMPLES AND INSTRUCTIONS FOR LAYING METHODS



1: Choose the "PROSTYLE WOOD" with suitable height for the thickness of the covering of the step or staircase. 2: Apply the adhesive onto the area of application of the profile. 3: Lay and align the profile, cut to the necessary length, pressing the perforated flange into the adhesive. 4: Lay the step covering, aligning it so that the top edge of the profile is "flush" with the covering. 5: Fill the profile/covering area of contact with adhesive to prevent any infiltration.