


**PROLEVALL 358** are transition profiles in polished extruded brass, available in the self-adhesive or punched versions. They are used to give a clean-cut, elegant finish when joining and compensating differences in level of floors that are already laid and in differing or same materials e.g. ceramic tiles-wood-parquet-marble, etc. They join and compensate a thickness between 7 and 9 mm. **PROLEVALL 358** ensures a perfect finish with little height, covering any flaws created during laying, while the contoured edges guarantee perfect adherence to the floor.

## PROLEVALL 358

POLISHED BRASS  
WITH SELF-ADHESIVE AND PUNCHED



PLVOL 358A/PLVOL 3589AS  
PLVOL 358F/PLVOL 3589FS



**POLISHED BRASS thermo packed** - bar length 2,7 lm  
pack. 20 Pcs - 54 lm (PLVOL 358F: 15 Pcs - 40,5 lm)


Article	L x H mm		
PLVOL 358A (with adhesive)	35 X 8		
PLVOL 358F (punched)	35 X 8		*

**POLISHED BRASS thermo packed**  
bar length 0,90 lm - pack. 20 Pc

Article	L x H mm		
PLVOL 3589AS (with adhesive)	35 X 8		
PLVOL 3589FS (punched with screws and screw anchors)	35 X 8		



### EXAMPLES AND INSTRUCTIONS FOR LAYING METHODS



#### Adhesive version

1. Choose the suitable profile and cut it to the necessary length.
2. Degrease, wash and clean the solid surface thoroughly.
3. Remove the protective paper from the adhesive.
4. Lay the profile by applying pressure evenly over the whole surface without using a hammer.

#### Punched version

1. Choose the suitable profile and cut it to the necessary length.
2. Mark the position of the holes using the existing holes in the profile as reference.
3. Insert the screw anchors into the drilled holes.
4. Fix the profile using flathead screws suitable for the relative slots in the profile.

### COLOURS



OL - Polished brass


**PROLEVALL 4413** are transition profiles in polished extruded brass and anodized aluminium available in the self-adhesive or punched versions. They are used to give a clean-cut, elegant finish when joining and compensating differences in level of floors that are already laid and in differing or same materials e.g. ceramic tiles-wood-parquet-marble, etc. They join and compensate a thickness between 13 and 15 mm. **PROLEVALL 4413** ensures a perfect finish with little height, covering any flaws created during laying, while the contoured edges guarantee perfect adherence to the floor.

## PROLEVALL 4413


POLISHED BRASS AND  
ANODIZED SILVER ALUMINIUM  
WITH SELF-ADHESIVE AND PUNCHED



PLVOL 4413A /PLVOL 44139AS  
PLVOL 4413F /PLVOL 44139FS



PLV... 4413A /PLV... 4413F



transition profiles

**POLISHED BRASS thermo packed**  
bar length 2,7 lm - pack. 10 Pcs - 27 lm

Article	L x H mm		
PLVOL 4413A (with adhesive)	44 X 13		*
PLVOL 4413F (punched)	44 X 13		*

**POLISHED BRASS thermo packed**  
bar length 0,90 lm - pack. 20 Pc

Article	L x H mm		
PLVOL 44139AS (with adhesive)	44 X 13		*
PLVOL 44139FS (punched with screws and screw anchors)	44 X 13		*




**ANODIZED SILVER and GOLD ALUMINIUM thermo packed**  
bar length 2,7 lm - pack. 20 Pcs - 54 lm

Article	L x H mm		
PLV... 4413A (with adhesive)	44 X 13		
PLV... 4413F (punched)	44 X 13		

Available in the colours: AA - AO (OL, AT, CH e SB available on demand with a minimum quantity order of 100 pcs). The code of the selected colour must be added to the article code. E.g.: PLV... 4413F (chosen colour anodized gold alum.) PLVAO 4413F.

### COLOURS



AA - Anodized silver alum.

AO - Anodized gold alum.

### AVAILABLE MINIMUM QUANTITY 100 PCS by color and height



OL - Polished brass


AT - Anodized titanium alum.

CH - Anod. champagne alum.

SB - Anodized sand alum.

(Price to be agreed. Production delay 4/5 weeks)

### EXAMPLES AND INSTRUCTIONS FOR LAYING METHODS



#### Adhesive version

1. Choose the suitable profile and cut it to the necessary length.
2. Degrease, wash and clean the solid surface thoroughly.
3. Remove the protective paper from the adhesive.
4. Lay the profile by applying pressure evenly over the whole surface without using a hammer.

#### Punched version

1. Choose the suitable profile and cut it to the necessary length.
2. Mark the position of the holes using the existing holes in the profile as reference.
3. Insert the screw anchors into the drilled holes.
4. Fix the profile using flathead screws suitable for the relative slots in the profile.

\* = Production on demand with minimum quantity of 100 pcs. Production delay 4/5 weeks. Price to be agreed